


REALME

Android 11 - realme UI 2


# HOW TO ADD A WI-FI NETWORK MANUALLY




Tap on  
Settings



Tap on  
Wi-Fi



Tap on  
Manually add a  
network



Enter the  
**SSID/Password** and  
tap **Save**

Done!