


REALME

Android 11 - realme UI 2


HOW TO ALLOW/DENY CALLS (DO NOT DISTURB)




Tap on
Settings




Tap on Sound & vibration



Tap on Do Not Disturb



Tap on
Allow calls from



Choose an Option

Done!