


REALME

Android 11 - realme UI 2


HOW TO AUTO CONNECT TO THE BEST WI-FI NETWORK




Tap on
Settings




Tap on
Wi-Fi



Tap on Advanced settings



Tap on Wi-Fi Assistant



Turn On/Off Auto connect to the best Wi-Fi

Done!