

REALME


Android 11 - realme UI 2

HOW TO TURN ON/OFF AUTOMATIC NETWORK SELECTION


TechBone




Tap on
Settings




Tap on
SIM card &
mobile data



Choose a SIM card (Dual SIM)



Tap on
Carrier



Turn On/Off Auto select

Done!