


REALME

Android 11 - realme UI 2


AUTO-OPTIMIZE BATTERY USAGE FOR BACKGROUND APPS




Tap on
Settings




Tap on Battery




Tap on
More battery settings



Tap on
Optimize battery use



Choose an App



Choose an Option

Done!