


REALME

Android 11 - realme UI 2


HOW TO CHANGE AP BAND (PERSONAL HOTSPOT)




Tap on
Settings




Tap on Connection & sharing




Tap on Personal hotspot




Tap on
Personal hotspot
settings



Tap on
AP band



Choose
2.4 GHz band or
5 GHz band



Tap on
Save

Done!