


REALME

Android 11 - realme UI 2


HOW TO CHANGE REGION




Tap on
Settings




Tap on Additional settings



Tap on Language & region



Tap on
Region



Set the Region

Done!