

REALME

Android 11 - realme UI 2


ALLOW/RESTRICT BACKGROUND ACTIVITY OF APPS






Tap on Settings






Tap on Battery






Tap on App battery management






Choose an App





Turn On/Off Allow background activity





Tapon Allow



Done.

