

REALME

Android 11 - realme UI 2


HOW TO CHANGE SYSTEM LANGUAGE






Tap on Settings






Tap on Additional settings






Tap on Language & region





Tapon Add a language or drag a Language to the first position





Tap on Change to...



Done.

