


REALME

Android 11 - realme UI 2


HOW TO SCHEDULE EYE COMFORT




Tap on
Settings




Tap on Display & brightness



Tap on
Eye comfort



Turn On/Off Schedule Time



Set the Start/End time

Done!