


REALME

Android 11 - realme UI 2


HOW TO SET APP ANIMATION SPEED




Tap on
Settings



Tap on Home screen & Lock screen



Tap on App animation speed



Choose an Option

Done!