



REALME

Phone - Android 11 - realme UI 2


# HOW TO TURN ON/OFF AUTOMATIC CALL ANSWERING




# Tap on Phone




# Open the Menu




# Tap on Settings




# Tap on Calling accounts



# Tap on Auto answer



# Turn On/Off Auto answer



# Set the Delay



Done!