


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF EYE COMFORT




Tap on
Settings



Tap on
Display & brightness




Tap on
Eye comfort



Turn On/Off

Always on



Set the Screen color temperature

Done!