

REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF ICON AUTOFILL






Tap on Settings





Tap on Home screen & Lock screen





Turn On/Off Lcon autofill



Done.

