


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF NFC



Tap on
Settings



Tap on Connection & sharing



Turn On/Off NFC

Done!