


REALME

Android 11 - realme UI 2


HOW TO REMOVE AN ACCOUNT




Tap on
Settings




Tap on Users & accounts




Choose an Account



Open the Menu



Tap on
Remove account



Tap on
Remove account
to confirm

Done!