


REALME

Android 11 - realme UI 2


HOW TO SET A DATA LIMIT (PERSONAL HOTSPOT)




Tap on
Settings




Tap on Connection & sharing




Tap on Personal hotspot



Tap on Connection management



Tap on
Data restriction



Choose an
Option

Done!