


REALME

Android 11 - realme UI 2


# HOW TO SET DEFAULT SIM CARD FOR INTERNET




Tap on  
Settings



Tap on  
SIM card &  
mobile data



Tap on  
Internet



# Choose SIM1 or SIM2

Done!