


REALME

Android 11 - realme UI 2


HOW TO SET DEFAULT USB CONFIGURATION




Tap on
Settings




Tap on Additional settings



Tap on Developer options



Tap on Default USB configuration



Choose an Option

Done!