


REALME

Android 11 - realme UI 2


# HOW TO SET SOS MESSAGES CONTENT




Tap on  
Settings




# Tap on Security




# Tap on Emergency SOS



Tap on  
Emergency call



# Turn On/Off Auto send SOS messages



# Turn On/Off an Option



Done!