


REALME

Android 11 - realme UI 2


# HOW TO SET TOUCH & HOLD DELAY




Tap on  
Settings




# Tap on Additional settings



# Tap on Accessibility



# Tap on Touch & hold delay



# Choose an Option

Done!