



REALME

Android 11 - realme UI 2


HOW TO SET UP FINGERPRINT UNLOCK




Tap on
Settings



Tap on
Password & biometrics



Tap on
Add fingerprint



Place the
Finger on the sensor
and follow the
instructions

Done!