




REALME

Android 11 - realme UI 2


HOW TO SHOW/HIDE WORLD CLOCK ON HOME SCREEN




Tap on
Settings



Tap on Additional settings



Tap on
Date & time



Turn On/Off Home screen world clock

Done!