


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF BLUETOOTH



Tap on
Settings



Tap on Bluetooth



Turn On/Off Bluetooth

Done!