


REALME

Android 11 - realme UI 2


# HOW TO TURN ON/OFF DO NOT DISTURB



Tap on  
Settings



# Tap on Sound & vibration



# Turn On/Off Do Not Disturb

Done!