


REALME

Android 11 - realme UI 2


# HOW TO TURN ON/OFF LOCATION



Tap on  
Settings



# Tap on Location



# Turn On/Off Location

Done!