


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF PHONE CALLS & SMS FOR USER




Tap on
Settings




Tap on Users & accounts



Tap on Multiple users



Tap on
Settings



Turn On/Off Allow calls and messages

Done!