

#### REALME

Android 11 - realme UI 2


#### HOW TO TURN ON/OFF POWER SAVING MODE






# Tap on Settings





## Tap on Battery





## Turn On/Off Power saving mode



#### Done.

