


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF SIM CARD LOCK




Tap on
Settings




Tap on Security




Tap on
SIM card lock



Choose a SIM Card (Dual SIM)



Turn On/Off Lock SIM card



Enter the
Current PIN and tap
on **Save**

Done!