



REALME

Android 11 - realme UI 2


# HOW TO TURN ON/OFF TOUCH SOUNDS




Tap on  
Settings



Tap on  
Sound & vibration



# Tap on More sounds & haptics



# Turn On/Off Touch sounds

# Done!