


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF ULTRA STANDBY MODE




Tap on
Settings




Tap on
Battery




Tap on
More battery settings



Tap on
Optimized standby



Choose an Option



Tap on
Turn on

Done!