


REALME

Android 11 - realme UI 2


HOW TO TURN ON/OFF WI-FI OR BLUETOOTH SCANNING




Tap on
Settings



Tap on Location



Tap on Wi-Fi and Bluetooth scanning



Turn On/Off Wi-Fi/Bluetooth scanning

Done!