


REALME

Android 11 - realme UI 2


HOW TO UNINSTALL APP UPDATES




Tap on
Settings




Tap on App management




Tap on App list




Choose an App



Open the Menu



Tap on Uninstall updates



Tap on
OK

Done!