



SAMSUNG

Android 11 - One UI 3


HOW TO AUTO RECONNECT TO WI-FI NETWORK




Tap on
Settings




Tap on Connections



Tap on Wi-Fi



Tap on
Settings



Turn On/Off Auto reconnect

Done!