



SAMSUNG

Android 11 - One UI 3


HOW TO CONNECT DEVICE VIA WI-FI DIRECT




Tap on
Settings




Tap on Connections




Tap on Wi-Fi



Open the Menu



Tap on
Wi-Fi Direct



Tap on an **Available**
device to connect

Done!