


SAMSUNG

Calendar - Android 11 - One UI 3


# HOW TO SET DEFAULT REMINDER TIME FOR EVENTS




# Tap on Calendar




Open the  
Menu




# Tap on Settings



# Tap on Alert settings



# Choose Events or All-day events



# Choose an Option

Done!