



SAMSUNG

Android 11 - One UI 3


HOW TO SET DEFAULT SIM CARD FOR TEXT MESSAGES




Tap on
Settings




Tap on Connections



Tap on SIM card manager



Tap on
Messages



Choose an Option

Done!