


SAMSUNG

Android 11 - One UI 3


HOW TO TURN ON/OFF EASY MODE




Tap on
Settings



Tap on
Display



Tap on Easy mode



Turn On/Off Easy mode

Done!