



SAMSUNG

Phone - Android 11 - One UI 3


# HOW TO SET POWER BUTTON TO END CALLS




Tap on  
Phone




# Open the Menu



Tap on  
Settings



# Tap on Answering and ending calls



# Turn On/Off

# Press Side key to end calls

Done!