



SAMSUNG

Android 11 - One UI 3

HOW TO TURN ON/OFF CAMERA OR SCREEN FLASH NOTIFICATION




Tap on
Settings




Tap on Accessibility


TechBone



Tap on
Advanced settings



Tap on Flash notification



Turn On/Off Camera / Screen flash notification

Done!