



SAMSUNG

Android 11 - One UI 3


HOW TO FORGET A WI-FI NETWORK




Tap on
Settings




Tap on Connections




Tap on Wi-Fi




Open the Menu




Tap on
Advanced



Tap on Manage networks



Choose a Saved network



Tap on
Forget

Done!