

SAMSUNG

Android 11 - One UI 3


HOW TO CHANGE PREFERRED NETWORK MODE




Tap on Settings



Tap on Connections




Tap on Mobile networks



Tap on

Network mode SIM 1 / 2



Choose an Option

TechBone

Done!