


SAMSUNG

Android 11 - One UI 3


HOW TO CHANGE NOTIFICATION VIBRATION PATTERN




Tap on
Settings



Tap on Sounds and vibration



Tap on Notification vibration pattern



Choose an Option

Done!