


# SAMSUNG

Android 11 - One UI 3


# HOW TO RESET ACCESSIBILITY SETTINGS




Tap on  
Settings




# Tap on General management




Tap on  
Reset



# Tap on Reset accessibility settings



Tap on  
Reset settings



Tap on  
Reset

Done!