


SAMSUNG

Android 11 - One UI 3


HOW TO RESET NETWORK SETTINGS




Tap on Settings




Tap on General management




Tap on
Reset



Tap on Reset network settings



Tap on
Reset settings



Tap on
Reset

Done!