


SAMSUNG

Android 11 - One UI 3


HOW TO RESTORE DEFAULT APP ICONS




Tap on
Settings




Tap on
Themes




Open the Menu




Tap on
My stuff



Tap on Icons



Choose Default



Tap on
Apply

Done!