



SAMSUNG

Android 11 - One UI 3


HOW TO TURN ON/OFF ROAMING CLOCK




Tap on
Settings




Tap on Lock screen



Tap on
Roaming clock



Turn On/Off Roaming clock



Set the **Home time zone**
and turn on/off **Show on**
Always On Display

Done!