



XIAOMI

Android 11 - MIUI 12


# HOW TO ALLOW INCOMING CALLS (DO NOT DISTURB)




Tap on **Settings**




Tap on  
Sound & vibration



Tap on  
Do not disturb



# Tap on Allow incoming calls



# Choose an **option**



# Done!