



XIAOMI

Android 11 - MIUI 12


HOW TO TURN ON/OFF AUTOMATIC BRIGHTNESS




Tap on **Settings**



Tap on **Display**



Tap on
Brightness level



Turn On/Off Automatic brightness

Done!