


XIAOMI

Android 11 - MIUI 12


HOW TO SHOW CONNECTION SPEED IN STATUS BAR




Tap on **Settings**



Tap on Notifications & Control center



Tap on Status bar



Turn On/Off Show connection speed

Done!